



Revised
7.14.05

2360 Boswell Road
Chula Vista, CA 91914
Phone 619.216.1444
Fax 619.216.1474
E-Mail tech@explorerprocomp.com

PRO COMP SUSPENSION

Suspension Systems that Work!

INSTRUCTIONS:

Bill Of Materials

Part #	Description	Qty.
90-3242	REAR SHOCK BRACKET	1

PART# 90-3242
Super Duty
Rear Shock
Bracket

Installation Instructions:

1. If installing 9000 series shocks, **ON THE DRIVER SIDE ONLY** remove the factory lower shock bracket and replace it with shock bracket (90-3242). Secure the bracket to the axle using the previously removed OE hardware. Torque the U-bolt hardware to 30 ft./lbs.

----- CUT HERE -----



Revised
7.14.05

2360 Boswell Road
Chula Vista, CA 91914
Phone 619.216.1444
Fax 619.216.1474
E-Mail tech@explorerprocomp.com

PRO COMP SUSPENSION

Suspension Systems that Work!

INSTRUCTIONS:

Bill Of Materials

Part #	Description	Qty.
90-3242	REAR SHOCK BRACKET	1

PART# 90-3242
Super Duty
Rear Shock
Bracket

Installation Instructions:

1. If installing 9000 series shocks, **ON THE DRIVER SIDE ONLY** remove the factory lower shock bracket and replace it with shock bracket (90-3242). Secure the bracket to the axle using the previously removed OE hardware. Torque the U-bolt hardware to 30 ft./lbs.