



Revised  
9.23.05

2360 Boswell Road  
Chula Vista, CA 91914  
Phone 619.216.1444  
Fax 619.216.1474  
E-Mail tech@explorerprocomp.com

## PRO COMP SUSPENSION

*Suspension Systems that Work!*

### INSTRUCTIONS:

Bill Of Materials

Part #	Description	Qty.
90-6428	HARDWARE PACK	-
600000	5/8" URETHANE HOURGLASS BUSHING	2
54314	SHOCK SLEEVE 1/2" X 5/8" X 1"	2

**PART# 90-6428**  
**Super Duty**  
**Double Shock**  
**Hoop Sleeves &**  
**Bushings**

### INSTRUCTIONS:

If you are installing this double shock hoop kit on a vehicle that has a **5"** or **7"** Pro Comp suspension lift kit that contained **MX6** or **MX6R** front shocks you may reuse the front shocks. To do this remove the bushing and sleeve in the lower shock mount and install a **600000** and a **54314** in the bottom. You will still need to purchase the remaining two front shocks depending on your application.

**5" LIFT:   MX6 MX6129**  
  
**MX6R MX6065R**

**7" LIFT:   MX6 MX6128**  
  
**MX6R MX6066R**